




NOTE: THE UPPER PLOW ARM ASSEMBLY FOR THE DT-140 & 141 AND DT-145 & 146 INCLUDE THE ATTITUDE CYLINDER.

### MATERIAL LIST

ITEM	QTY.	DESCRIPTION	PART NUMBER
1	1	UPPER PLOW ARM ASSY DT-140 & 141	3151-3000
	1	UPPER PLOW ARM ASSY DT-145 & 146	3151-3100
2	1	LOWER PLOW ARM ASSY DT-140 & 141	3151-4000
	1	LOWER PLOW ARM ASSY DT-145 & 146	3151-4100
3	6	2.5"ID X 3"OD X 3" LG BUSHING	3252-0002
4	4	PLOW ARM PIN & BOLT	3252-0026
5	1	ATTITUDE CYLINDER	3416-2203
6	3	3 ID x 5 OD STEEL BOSS	3252-0080
7	1	STEEL PIN	3252-0031
8	1	LIFT STOP	3252-0035
9	1	Collar	3252-0052
10	1	Hose Collector	3151-3079
11	1	Style 2 Pin	3252-4025



WARNING: UPPER AND LOWER PLOW ARMS FOR THE DT-140 & 141, 63" AND DT-145 & 146, 69" ARE DIFFERENT LENGTHS AND CANNOT BE MIXED ON THE SAME TRACTOR.

*UPPER & LOWER PLOW ARM ASSY'S  
DELTA MACHINE PRODUCTS, INC.*